



General data

Various pushbuttons for mounting hole diameters from 9.1 mm to 30.3 mm.

Content

Pushbutton opaque, mounting hole diameter 9.1 mm, non-illuminated, 24 V/100 mA	1 - 76
Pushbutton opaque, mounting hole diameter 9.1 mm, non-illuminated, 24 V/0.1 A	1 - 77
Illuminable pushbutton, mounting hole diameter 9.1 mm, 24 V/0.5 A	1 - 78
Illuminable pushbutton, mounting hole diameter 9.1 mm, 24 V/0.5 A	1 - 79
Pushbutton, opaque, mounting hole diameter 15.2 mm, 250 V/0.7 A	1 - 80
Pushbutton, opaque, mounting hole diameter 15.2 mm	1 - 81
Pushbutton, opaque, mounting hole diameter 16.2 mm, 250 V/2 A	1 - 82
Pushbutton, opaque, mounting hole diameter 16.2 mm, 250 V/2 A	1 - 83
Pushbutton, opaque, mounting hole diameter 18.2 mm, 250 V/2 A	1 - 84
Pushbutton, opaque, mounting hole diameter 18.2 mm, 250 V/2 A	1 - 85
Illuminable pushbutton, with lamp socket BA9s (MBC/MCC), mounting hole diameter 20.3 mm, 250 V/2 A	1 - 86
Illuminable pushbutton, with lamp socket BA9s (MBC/MCC), mounting hole diameter 20.3 mm, 250 V/2 A	1 - 87
VARIOTAST V11 main switch	1 - 88
VARIOTAST V11 main switch	1 - 89

Other
Pushb.